


1. Drill hole $1/8''$ deeper than length of anchor.



2. Tap anchor into hole, flush with masonry.



3. Place fixture, insert screw, fasten with screwdriver.