

Installation Instructions



1. Loosen connector bolt(s) and separate halves.



2. Mount the main cable in the main groove of the connector by placing the connector halves over the cable.



3. Insert the squared-off tap cable into the tap groove until it contacts the end tab. Tighten the bolt(s) until securely fastened.



4. Completed installation.