



1. Drill hole



2. Install drive sleeve
over drill bit



3. Drive anchor