



To determine the proper length of Crete-Flex™ anchor for an application, combine the thickness of the attachment (A) with the desired depth of embedment in the masonry material (B). It is recommended that embedment never be less than 1", nor greater than 1-3/4".